

PARTS LIST 468300217, 468300217CH, 468300617

Key	Qty	Description
1	1	TOP LID
2	2	LID BUMPER, FRONT
3	2	LID BUMPER, REAR
4	1	LOGO PLATE
5	1	HANDLE
6	1	TEMPERATURE GAUGE
7	1	BEZEL, TEMPERATURE GAUGE
8	1	HARDWARE F/ TOP LID
9	1	FIREBOX
10	3	BURNER
11	3	HEAT TENT
12	2	FLAME CARRYOVER TUBE
13	1	ELECTRODE
14	1	GREASE CUP CLIP
15	1	GREASE CUP
16	3	COOKING GRATE
17	1	SWINGAWAY RACK
18	1	LEG, LEFT LOWER FRONT
19	1	LEG, LEFT LOWER REAR
20	2	SIDE PANEL, F/ CART
21	2	UPPER CART FRAME A
22	2	UPPER CART FRAME B
23	2	UPPER CART BRACE
24	1	LEG, RIGHT LOWER FRONT
25	1	LEG, RIGHT LOWER REAR
26	1	CONTROL PANEL
27	1	ELECTRONIC IGNITION MODULE
28	1	BUTTON, F/ EI MODULE
29	1	MATCH HOLDER
30	1	VALVE HOSE ASSEMBLY
31	1	FRONT PANEL, MIDDLE
32	1	FRONT PANEL, LOWER
33	1	FRONT PANEL, UPPER
34	1	HEAT SHIELD, TANK
35	1	CHARCOAL TRAY
36	4	CONTROL KNOB
37	4	BEZEL, F/ CONTROL KNOB
38	6	END CAP, F/ LEG
39	2	WHEEL
40	1	AXLE
41	1	STORAGE TRAY
42	1	BOTTOM SHELF
43	1	HOT PLATE SHELF
44	1	DRIP PAN, F/ HOT PLATE
45	1	HOT PLATE
46	1	ELECTRODE, F/ HOT PLATE
47	1	IGNITOR WIRE, F/ HOT PLATE
48	1	HOT PLATE GRATE
49	1	HOT PLATE LID
50	1	RIGHT SHELF ASSEMBLY
51	1	HEAT SHIELD, F/ EI MODULE
52	1	HEAT SHIELD, F/ HANDLE
53	3	BURNER BRACE

NOT Pictured

...	1	HARDWARE PACK
...	1	PRODUCT GUIDE, EUROPE
...	1	RETAINER CLIP, F/ HOT PLATE

Teilelist 468300217, 468300217CH, 468300617

Key	Qty	Description
1	1	Deckel
2	2	Dämpfer f. Deckel, vorne
3	2	Dämpfer f. Deckel, hinten
4	1	Logo-Schild
5	1	Griff
6	1	Thermometer
7	1	Blende, Thermometer
8	1	Schrauben f. Deckel
9	1	Brennkammer
10	3	Brenner
11	3	Hitze Deckel
12	2	Flammübertragungsrohr
13	1	Elektrode
14	1	Halterung f. Fettauffangschale
15	1	Fettauffangschale
16	3	Grillrost
17	1	schwenkbarer Rost
18	1	Bein, links unten vorne
19	1	Bein, links unten hinten
20	2	Seitenblech f. Wagen
21	2	Oberer Rahmen A, Wagen
22	2	Oberer Rahmen B, Wagen
23	2	Obere Halterung, Wagen
24	1	Bein, rechts unten vorne
25	1	Bein, rechts unten hinten
26	1	Bedienfeld
27	1	Elektronische Zündung
28	1	Zündschalter
29	1	Streichholzhalter
30	1	Ventil-Schlauch-Einheit
31	1	Frontblech, mitte
32	1	Frontblech, unten
33	1	Frontblech, oben
34	1	Separator
35	1	Kohlenschale
36	4	Schaltknopf
37	4	Blende f. Schaltknopf
38	6	Abdeckkappe, Bein
39	2	Rad
40	1	Achse
41	1	Ablageblech
42	1	Unterer Boden
43	1	Seitenbrenner Ablage
44	1	Tropfpanne, Heizplatte
45	1	Heizplatte
46	1	Elektrode f. Heizplatte
47	1	Zündkabel f. Heizplatte
48	1	Rost f. Heizplatte
49	1	Deckel f. Heizplatte
50	1	Ablage rechts
51	1	Hitzeschild f. Elektronische Einheit
52	1	Hitzeschild f. Griff
53	3	Brennerhalter

Nicht im Bild

...	1	Beschlagbeutel
...	1	Bedienungsanleitung, Europe
...	1	Clip, Heizplatte

PARTS DIAGRAM 468300217, 468300217CH, 468300617

